



Galileo Plus

Mist Collector





Galleo Plu

Galileo Plus is a patented centrifugal filter for mist generated from neat oil and emulsions used in machine tools, also suitable in the presence of particulate.

Galileo Plus is available in 5 models with throughputs from 325 to 3.500 m³/h.

Patented in Italy.

Patent pending in Europe, USA, China and Japan.




LOSMA grants that every single system is tested through strict control procedures. Every unit is provided with a qualitative and functional test certificate.





Working principles



- Polluted air is drawn from machine tool into the lower pre-chamber (A) of Galileo Plus.
- The acceleration effect, due to the centrifugal force generated by a rotating turbine, makes the oil particles bind together and return to liquid state, using the coalescence principle.
- A special Multilayer filter (B) having high filtration efficiency, stops and catches even the smallest pollutant particles, avoiding their dispersion in environment.
- Thanks to a special drainage tube (C) the liquid oil is sent back to the machine tool, to be re-used in working process.



Plus



HIGH FILTRATION LEVEL AND LONG LASTING FILTERS

The combination of the turbine centrifugal action and a high efficiency multilayer filter set guarantees a high filtration level. Filters are positioned after the centrifugal action of the turbine, thus they are exposed to a limited amount of polluting agents, having a small size. This location grants Galileo Plus's filters a longer life than the one of the most common centrifugal or static filters in the market.



REDUCED ELECTRICAL CONSUMPTION

Inspired to Blue Philosophy, Galileo Plus uses energy saving motors with high efficiency and very low power (KW) (see table at next page).



TESTED MATERIAL FROM LOSMA'S LABORATORIES

Galileo Plus internal materials passed compatibility stress tests, carried on with different types of neat oils and emulsions in the market.





SPECIAL TURBINE

Designed for avoiding dust settlement on its surface, secures no vibrations also in case of big quantities of particulate.



QUICK AND EASY MAINTENANCE

Internal filters can be cleaned or changed simple opening of a cover.



INNOVATIVE DESIGN

Galileo Plus combines the Italian design with cutting-edge technologies for a better working environment.

Optional

Filter clogging X-VIEW sensor

The new X-VIEW sensor is able to detect the progressive clogging state of the Galileo Plus filters, signalling three main operating phases (Led version):

GREEN: Clean Filters;YELLOW: Pre clogging;

RED: Clogging.











Patent application filed

Also thanks to an exclusive software, it is possible to detect possible ANOMALY conditions:

- Upstream obstructions (piping, grid, etc.);
- Zero flow.

Thanks to an integrated TIMER, X-VIEW sensor allows to know when 15,000 working hours (ex. 5 years/8 hours per day) have been achieved, which is the recommended threshold for the check of the filter set.

X-VIEW sensor can be positioned on Galileo Plus or in any other part of the machine tool where the operator is more comfortable reading the data. Thanks to the Self-learning button, it automatically

sets itself to the initial values, making installation extremely easy.

From that time, all flow changes are measured according to the GREEN, YELLOW, RED scale.

X-VIEW works with all accessories (G-Guard Plus, G-Clipper Plus, Horizontal input) and it can be integrated with the CNC of the machine tool (IoT Ready version), providing feedback in real time on the air filter conditions.



The sensor comes in two versions:

X-VIEW Led version

Through a luminous signal it shows:

- the filter clogging status: Clean Filters Preclogging - Clogging.
- Possible upstream obstructions: instantaneous or progressive obstructions of the inlet pipe or suction grid in the machine cabin (e.g. chip or liquid build-up).
- Zero flow alarm: e.g. Galileo Plus turned off, motor not working or turned off, piping disconnected).
- Timer: It indicates the achievement of 15,000 working hours (the threshold recommended for check of filters).

X-VIEW IoT Ready version

- Transmission of data directly to the CNC machine by cable related to:
- The filter clogging status: Cleaned Filters Preintasamento - Clogging.
- Possible upstream obstructions: instantaneous or progressive obstructions of the inlet pipe or suction grid in the machine cabin (e.g. chip or liquid build-up).
- Zero flow alarm: e.g. Galileo Plus turned off, motor not working or turned off, piping disconnected).
- Timer: It indicates the achievement of 15,000 working hours (the threshold recommended for check of filters).
- Remote or CNC control:
- Configuration conditions: possibility to configure the main monitoring parameters in real time.
- Re-setting of the alarms.
- Timer resetting.
- Zero flow.

Technical data


X-VIEW LED

• Voltage: 24V DC

Signal type: LED display

• Size: Dimensions: A = 110 mm

 \emptyset = 115 mm



X-VIEW IoT Ready

Voltage: 24V DC

Signal type: Digital

• Size: Dimensions: A = 110 mm

 $\emptyset = 115 \text{ mm}$



Optional



Post-filter cartridge for micromist, smoke and vapor. It allows to reach a high filtration level up to 99.97%.

G-Guard

Pre-filtration module useful to optimize air filtration efficiency, in case of high production of oil mist containing dust or swarf chips, also with high pressures. The G-Guard is washable.



Installations







Optional

Horizontal input


Ideal for installation at operator or trolley height.



Installations



Technical data



MODELS	Dimensions (mm)							
	ØA	<) B	øс	D	E	ØF		
GP 250	330	120	78	98	388	25		
GP 500	400	120	98	98	418	25		
GP 1000	490	120	148	88	508	25		
GP 2000	530	120	148	88	558	25		
GP 3000	560	120	198	88	658	25		

MODELS	Dimensions (mm)								
	ØG	н	1	J	K	L			
GP 250	254	314	700	93	789	99			
GP 500	315	314	730	113	838	118			
GP 1000	380	435	930	163	1083	168			
GP 2000	380	435	950	163	1133	168			
GP 3000	460	350	1025	218	1178	223			

MODELLI	Flow Rate (m³/h)*		Pressure (Pa)		Power		Inlet	Noise level (dBa)		Net Weight	RPM (rpm)	
	50 (Hz)	60 (Hz)	50 (Hz)	60 (Hz)	50 (Hz)	60 (Hz)	(mm)	50 (Hz)	60 (Hz)	(kg)	50 (Hz)	60 (Hz)
GP 250	325	450	320	410	0.09	0.12	80	58	60	10	2900	3450
GP 500	700	850	800	900	0.25	0.29	100	68	69	14	2900	3450
GP 1000	1520	1550	1000	1210	0.55	0.63	150	70	71	29	2800	3450
GP 2000	2160	2230	1100	1310	1.1	1.3	150	72	73	34	2900	3450
GP 3000	3400	3500	1300	1500	1.5	1.75	200	71	75	54	2900	3500

^{*} Free inlet.













Health

Savings

Efficiency

Environment

Safety



Losma SpA HQ:

Via E. Fermi, 16 - 24035 Curno - Bergamo Tel. +39 035 461444 info@losma.it - www.losma.it







ISO 9001 TÜV Italia Certified Company

ISO 14001 TÜV Italia Certified Company

Authorised to use

Losma SpA Turin office:

Via G. Brunero, 2 - 10077 San Maurizio Canavese - Torino Tel. +39 011 9278942 info@losma.it - www.losma.it

Losma GmbH

Siemensstr. 14/3 - 71691 Freiberg am Neckar Tel. +49 7141 / 89971-10 info@losma.de - www.losma.de



Losma Inc.

30A Wilson Drive - Sparta - NJ 07871 Tel. +1 973 300 1044 sales@losmausa.com - www.losma.com

Losma UK Ltd.
6 Strensham Business Park WR8 9JZ Strensham Worcestershire Tel. +44 1684 276527 info@losma.co.uk - www.losma.co.uk

Losma Pvt Ltd.

Plot No 7A, Gat. No. 63, Shindewadi Tal: Bhor, District: Pune - 412205 - Maharashtra Tel. +91 92261 07775 info@losma.in - www.losma.com